



Assembly Guide

TIPS

To detach the parts from the board, press the anchor point with your thumb.
Always push with your thumb on the engraved side of the board, so the piece falls under the board.
You can easily locate the anchors points by looking at the back of the board.
Use PVA glue diluted with a little water. (3 parts adhesive, 1 part of water).
Use a small file to remove the anchor points' residues. You can also use a modeler's knife (handle it carefully to prevent injury).
Use a small brush to spread the diluted glue.



Guide Walkway 2nd Level



Glue [A] and [B] to each side of part [C] making sure that the engraved symbol of [A] and [B] are outwards.



To complete a walkway, join two assemblages of [A], [B] and [C] by gluing them.
You can add extra walkway lengths to make them longer.

To solidify the assemblage, glue two parts [D] underneath.