



# Assembly Guide

## TIPS

To detach the parts from the board, press the anchor point with your thumb.  
 Always push with your thumb on the engraved side of the board, so the piece falls under the board.  
 You can easily locate the anchors points by looking at the back of the board.  
 Use PVA glue diluted with a little water. (3 parts adhesive, 1 part of water).  
 Use a small file to remove the anchor points' residues. You can also use a modeler's knife (handle it carefully to prevent injury).  
 Use a small brush to spread the diluted glue.



### Urban warzone B - Guide



Join [B5] and [B4]



Complete the assemblage with [B6]



Insert [B3] into [B1]



Insert [B2] on [B1] and [B3]



Insert [B8] into [B7].  
Do not allow time to dry



Insert [B10] into [B8] and [B7]. This requires slightly tilting [B8]



Insert [B11] by sliding it into [B11] until it fits into [B8]



Insert [B12] by sliding it into [B11] until it fits into [B8]



Insert [B13] into the large slot that runs through [B12] and [B11] up to [B7]



Slide [B14] into the base and below [B11]



Slide [B9] forward on the opposite side of the entrance, across from [B8]



The two staircases are assembled in the same way. Insert four parts [B16] into the two parts [B15] and four more into the parts [B18]



You will notice that the [B17] parts are wider than the [B16] and this is normal. The aim is to allow you to insert part [B17] into the wall to solidify the stairs.



The stairs formed by parts [B15] is placed at the bottom. Insert it into the floor and then slide a part [B17] into the last space at the top of the stairs. Continue pushing the part to insert it into the wall



Proceed in the same way for the staircase formed of parts [B18], then push it against the wall. Be delicate, because your staircase is probably not very solid at this stage.



You have 5 parts that look like this one for each of the windows. They form the windowsill.



The parts on the left represent planks or beams and the ones on the right represent pieces of broken concrete. We recommend that you glue the concrete parts now, but keep the beams to paint them separately and add to the models at the end, especially if you choose to use a textured spray on the models.

