



# Assembly Guide

## TIPS

To detach the parts from the board, press the anchor point with your thumb.  
 Always push with your thumb on the engraved side of the board, so the piece falls under the board.  
 You can easily locate the anchors points by looking at the back of the board.  
 Use PVA glue diluted with a little water. (3 parts adhesive, 1 part of water).  
 Use a small file to remove the anchor points' residues. You can also use a modeler's knife (handle it carefully to prevent injury).  
 Use a small brush to spread the diluted glue.



**Note :** If you attach several kits permanently, you do not need to use all feet.  
 The guard-rails are always composed of a male side and a female side. The male side is always to the right of the opening of the walkway so that you can join each kit to your liking.

## Guide Walkway Stairs



Insert parts [A and B] into each other.  
 Make sure to position the base of the foot flat,  
 in order to glue and level the two parts



You must insert each step [Q] into part [O]  
 and then part [R] representing the platform.



Without allowing time for the glue to dry,  
 add part [P] opposite to [O] by positioning the steps one  
 by one and the platform into the corresponding holes



Glue one foot (assemblage of [A and B]) under the platform [R]