



Assembly Guide

TIPS

To detach the parts from the board, press the anchor point with your thumb.
 Always push with your thumb on the engraved side of the board, so the piece falls under the board.
 You can easily locate the anchors points by looking at the back of the board.
 Use PVA glue diluted with a little water. (3 parts adhesive, 1 part of water).
 Use a small file to remove the anchor points' residues. You can also use a modeler's knife (handle it carefully to prevent injury).
 Use a small brush to spread the diluted glue.



Note : If you attach several kits permanently, you do not need to use all feet.
 The guard-rails are always composed of a male side and a female side. The male side is always to the right of the opening of the walkway so that you can join each kit to your liking.

Guide Walkway, Intersection



Insert parts [A and B] into each other. Make sure to position the base of the foot flat, in order to glue and level the two parts



For longer sections, take part [D] and glue one part [C] on each side as shown on the picture



Glue two feet (assembly of [A and B]) under each long section [D]



Glue one part [C] at the end of part [E]



Glue the [F] part to the side where there are two anchors points on part [E].
 Glue part [I] to the side where there are three anchors points on part [E]



Glue part [G] perpendicularly to part [I]



Glue part [H] perpendicularly to part [F]



Glue three feet, one at each end of part [E] for more stability