



Assembly Guide

TIPS

To detach the parts from the board, press the anchor point with your thumb.
 Always push with your thumb on the engraved side of the board, so the piece falls under the board.
 You can easily locate the anchors points by looking at the back of the board.
 Use PVA glue diluted with a little water. (3 parts adhesive, 1 part of water).
 Use a small file to remove the anchor points' residues. You can also use a modeler's knife (handle it carefully to prevent injury).
 Use a small brush to spread the diluted glue.



Urban warzone D - Guide



Insert [D2] into [D1] and insert [D5] into [D2]



Insert [D6] into [D2]



Add [D7] to form the last floor and close one side with [D4]



Close the other side with [D3]



Insert [D9] into [D8]



Insert [D10] into [D9] and then into [D8]. Insert [D13] into the top corner, forcing it slightly. But it should not be difficult.



Slide part [D11] on the same side as [D13]



Slide [D12] on the other side



Gather the thirteen parts [Z]



Position them as to form windowsills



The parts on the left represent planks or beams and the ones on the right represent pieces of broken concrete. We recommend that you glue the concrete parts now, but keep the beams to paint them separately and add to the models at the end, especially if you choose to use a textured spray on the models.

