



# Assembly Guide

**TIPS** To detach the parts from the board, press the anchor point with your thumb. Always push with your thumb on the engraved side of the board, so the piece falls under the board. You can easily locate the anchors points by looking at the back of the board. Use PVA glue diluted with a little water. (3 parts adhesive, 1 part of water). Use a small file to remove the anchor points' residues. You can also use a modeler's knife (handle it carefully to prevent injury). Use a small brush to spread the diluted glue.



**Do not allow drying time between the following steps**

## Guide - Paint Rack A & B

### Brush Holder



Glue each part [H] face to face on [K].



Join the two parts [H] with the part [I] on top



Add the two parts [J] on each empty side of [K], it helps to keep all the assembly upright.



Glue a part [E] on each part [D]. (Note that there is a right way to do this {see image}. Make sure you can insert the assemblage in the slots on [A].) Part [E] goes opposite of the slot at the top of part [A].



Glue the four [E and D] assemblages into the slots along [A].



Glue part [C] in the slot at the top of part [A]



Without waiting, glue the part [B] across from part [A], making sure to include every assemblage in the slots one by one.



Glue one part [F] to close each row. Hold part [F] in place for about a minute to make sure it is well positioned.



Both feet are optional. If you plan to use the holes at the top of the rack to hang on the wall, do not attach the feet. If you do not intend to hang your rack, the provided feet offer greater stability and will prevent the rack from tipping over.



You can also glue the brush holder to the side of the rack to have single piece of equipment.

