



# Assembly Guide

## TIPS

To detach the parts from the board, press the anchor point with your thumb.  
Always push with your thumb on the engraved side of the board, so the piece falls under the board.  
You can easily locate the anchors points by looking at the back of the board.  
Use PVA glue diluted with a little water. (3 parts adhesive, 1 part of water).  
Use a small file to remove the anchor points' residues. You can also use a modeler's knife (handle it carefully to prevent injury).  
Use a small brush to spread the diluted glue.



## Guide Mini Paint Station



Start with part [D] and insert both parts [H]



Insert the previous assemblage into part [B2]



Glue [G] and [F] together and insert them in part [B2]



Glue [B1] to the other end. Be patient as it is not easy to insert 3 tips at the same time.



Glue the assemblage onto [A]



Add part [E] at the front



Finally, insert part [C] on top of both [B1] and [B2]