

WHAT TO DO FOR THE INSTALLATION OF THE UNCOUPLING MEMBRANE

Read instructions before starting the installation

Standard Uncoupling membrane with fleece

Ceramic and natural stone

- Ensure the floor is smooth and free of debris and prior adhesives.
- Can be installed on plywood, OSB and concrete subfloors.
- Wood subfloors should be prepared for tiling in accordance with local tiling standards such as ANSI A108 series.
- Requires a modified thinset applied with a $\frac{1}{4} \times \frac{1}{4}$ trowel or the DrexBond applied with a $\frac{1}{8} \times \frac{1}{8}$ trowel.
- Press the DrexMat on to the thinset or the DrexBond and verify for a full contact.
- Tile installation can start immediately if using a quick set thinset.
- Read and understand the instructions before starting the work.

Soft floor covering

- Ensure the floor is smooth and free of debris and prior adhesives.
- Can be installed on plywood, OSB and concrete subfloors.
- Wood subfloors should be prepared for tiling in accordance with local tiling standards such as ANSI A108 series.
- Requires a modified thinset applied with a $\frac{1}{4} \times \frac{1}{4}$ trowel or the DrexBond applied with a $\frac{1}{8} \times \frac{1}{8}$ trowel.
- Press the DrexMat on to the thinset or the DrexBond and verify for a full contact.
- Pour a minimum of $\frac{3}{8}$ of leveler above the DrexMat.
- Always apply the leveler in one pour (layer).
- Read and understand the instructions before starting the work.

