



Warm Feet
 119A, Sir Wilfrid Laurier
 Saint-Basile-Le-Grand, QC J3N 1A1
 T. Free 1-866-994-4664

Floor heating cable test log

Homeowner/Job Location information

| | |
|----------------|----------|
| Name | Phone |
| Address | Email |
| City | State |
| Invoice Number | Job Name |

Electrician Information

| | | |
|--------------|-------|-----|
| Company Name | | |
| Address | | |
| City | State | Zip |
| Inst. Name | Tel. | |

Installer Information

| | | |
|--------------|-------|-----|
| Company Name | | |
| Address | | |
| City | State | Zip |
| Inst. Name | Tel. | |

| Model Number | Factory Value | Before Installation | After Cable Installation | After Tile Installation |
|--------------|---------------|---------------------|--------------------------|-------------------------|
|--------------|---------------|---------------------|--------------------------|-------------------------|

| | | | | |
|----------------|--|--|--|--|
| Test 1: | Conductor Resistance Test-Feedings must fall within 10% of the factory value printed on the heating cable identification tag using a multimeter. | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

| | | | | |
|----------------|---|--|--|--|
| Test 2: | Conductors and Ground Braid continuity Test Using A Multimeter. | | | |
|----------------|---|--|--|--|

| | | | | |
|--|--------------------------------|--|--|--|
| | Infini (I) or Overload (OL) | | | |
| | | | | |
| | | | | |
| | | | | |

| | | | | |
|----------------|---|--|--|--|
| Test 3: | Insulation Resistance Test Using a Megger | | | |
|----------------|---|--|--|--|

| | | | | |
|--|---|--|--|--|
| | Equal to or greater than 1 Gigaohms | | | |
| | | | | |
| | | | | |
| | | | | |

| | | | | |
|------------------------|--|--|--|--|
| Floor Temperature Test | | | | |
|------------------------|--|--|--|--|

| | Temperature | | Resistance | | |
|--|-------------|----|------------|--|--|
| | °C | °F | K ohms | | |
| | 10 | 50 | 19.9 | | |
| | 15 | 59 | 15.7 | | |
| | 20 | 68 | 12.5 | | |
| | 25 | 77 | 10.0 | | |
| | 30 | 86 | 8.0 | | |

Allow the assembly to cure for 28 days after grouting before putting the floor warming into service.

Free Technical support - Free advice - Warm Feet 1-866-994-4664